

Resetting the Water Block

The Water Block is an Overflow safety device controls the maximum consumption of water between 1 and 3 gallons. Device measures the number of gallons of water that have passed through it; if this quantity exceeds the set value, the Pentair Everpure Water Block stops the flow and maintains this safety condition until user intervention

If the water volume does not exceed the set value, the Pentair Everpure Water Block mechanically and automatically resets the measured volume and is ready to restart a new measurement cycle

1



When You are not getting water out of the spigot it could be due to the water block tripping. To reset the water block, find the red trigger and push in until you feel water running through the machine

2

